

Installing your Raspberry Pi




As part of our support offering to your school, the Raspberry Pi will assist N4L to proactively monitor the health and performance of your connection to the Managed Network, ensuring any potential issues can be identified early and resolved.

This pack contains the following items:



1
RASPBERRY PI
& SD CARD




2
USB CABLE



3
PATCH LEAD


Installation Instructions:

The Raspberry Pi needs to be plugged into your Managed Router (the box located in your server room installed at time of getting connected) in order to function as it should. This is a simple process that anyone can do by following these easy steps.




Step 1

Locate port GE 0/2 on the N4L Managed Router and plug one end of the patch lead into the port (note: the lead will click into place).



Step 2

Plug the other end of the patch lead into the Raspberry Pi (note: the lead will click into place).



Step 3

Insert the small end of the USB cable into the mini USB port on the side of the Raspberry Pi.



Step 4

Plug both the larger dual-connector ends of the USB cable into the two USB ports on your N4L Managed Router.

Your Raspberry Pi will now turn on, indicated by the lights illuminating.

If you have any questions contact N4L's Helpdesk team:

Monday to Friday, 8am - 5pm

W www.n4l.co.nz

P 0800 LEARNING

E support@n4l.co.nz